

 **UTILITY
SOLUTIONS**
POWER(FUL) INNOVATION.
REX CLAMP™
USER MANUAL

C-00268
(1-24-23)



The Rex Clamp™ is an easy-to-use clamp designed to control tails when using a Come Along or strap hoist type pulling device.


Features:

- Variable width jaw notches accommodate ACSR conductor sizes from #6 through 750 MCM.
- Clamp can be set tight to the conductor or allowed to slide if needed.
- Integrated slot can accommodate single straps up to 3" wide.

To avoid breaking, do not attempt to load more than 1 strap in the slot.


- Rotating arm engages to provide positive lock to strap and conductor.

STEP 1




Slide clamp over strap.
Place the tail in the jaws.

STEP 2



Lock the rotating arm in
place.

STEP 3



If desired, set the clamp
tight to the conductor, or
allow it to slide by using a
larger slot.



(828) 323-8914



(828) 323-8410



sales@utilityolutionsinc.com



utilityolutionsinc.com

101 33RD STREET DRIVE SE • HICKORY, NC 28602